

FILL-RITE®

HAND AND AIR OPERATED PUMPS

FR20V, FRHP32V, FRAP32V
Installation and Operation Manual



Thank You!

Thank you for your loyalty to the Fill-Rite® brand of fuel transfer pumps. Your safety is important, so please read and thoroughly understand the procedures set forth in this manual. In addition, please save these instructions for future reference and record the model, serial number, and purchase date of your fuel transfer pump. Protect yourself as well as those around you by observing all safety instructions and adhering to all danger, warning, and caution symbols. Please register your Fill-Rite® product via info.fillrite.com/product_registration.





IMPORTANT RETURN POLICY

Please do not return this product to the store. For all warranty and product questions, please contact Fill-Rite Technical Support at 1 (800) 720-5192 or via email at FillRiteTech@fillrite.com (M-F, 8 AM – 5 PM ET).

About This Manual

From initial concept and design through final production, your Fill-Rite fuel transfer pump is built to provide years of trouble-free use. To ensure the safety of yourself and those around you, it is critical that this manual is read in its entirety prior to attempting to install or operate your new purchase. We strongly urge that any installer and operator become familiar with the terms, diagrams, and technical data in this manual and pay close attention to warning symbols and definitions. At Fill-Rite, your satisfaction with our products is paramount. If you have questions or need assistance with your product, please contact Fill-Rite Technical Support at 1 (800) 720-5192 (M-F, 8am-5pm ET).

Symbols and Definitions

	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in moderate or minor injury.
	Indicates information considered important but not directly hazard related.

Safety Information

To ensure a safe installation and proper equipment operation, please read, understand, and adhere to all DANGER/WARNING/CAUTION and other NOTICES.

WARNING

To ensure safe and proper operation of your equipment, it is critical to read and adhere to all of the following safety warnings and precautions. Improper installation or use of this product can cause damage to the device and serious bodily injury or death!

1. When using the FRHP32V and FRAP32V with Diesel Exhaust Fluid, maintaining the purity of the DEF / AUS32 (Aqueous Urea Solution 32.5%) is critical; as such, it is imperative once the system is assembled, it must remain sealed to ensure the integrity of the fluid. Breaking the seal on the system can lead to fluid contamination.
2. After dispensing DEF be certain to drain all the fluid from the nozzle, making sure it is pointing downward when stored. DEF remaining in the nozzle tip and exposed to air will crystallize and can plug the nozzle.
3. DO NOT lay the dispensing nozzle on the ground or any surface that may contaminate the nozzle tip as this can compromise the purity of the DEF.
4. The base is designed to mount directly to the barrel bung; as such it has 2" NPS threads. Plumbing sealant appropriate for the fluids and chemicals being dispensed is highly recommended; the 2" threaded bung mount does not require sealant.
5. Storage tanks should be securely anchored to prevent shifting or tipping when full or empty.
6. If the pump will see periods of low or no use, flush it regularly when pumping DEF, corrosive materials, or fluids that harden. If the pump is used for DEF, use only DEF or de-ionized water to flush the pump (FRHP32V and FRAP32V applications).
7. DO NOT use the pump with fluids intended for human consumption.
8. This pump is not for use with fluids that have a flash point below 100°F (37.8°C, ie: gasoline, alcohol). Refer to NFPA 325M (Fire Hazard Properties of Flammable Liquids, Gases, and Volatile Solids) for flash points of common liquids. Static electricity buildup and discharge could result in arc and explosion.
9. On hand operated pumps, leave the handle in the down position when not in use to prevent accidental dispensing of fluid.

Installation

FR20V AND FRHP32V HAND OPERATED PUMPS

1. Apply thread sealant tape or compound (appropriate for the fluid to be pumped) to the suction tube threads; screw tube into the pump inlet.
2. Slide suction pipe into tank or barrel.
3. Screw pump into tank or barrel application until the spout faces the desired direction for dispensing.
4. Tighten the lock ring securely onto the tank or barrel.
5. If applicable, attach dispensing hose to spout outlet; clamp securely in place.

FRAP32V AIR OPERATED PUMP

1. Apply thread sealant or compound (appropriate for the fluid to be pumped) to the suction tube threads; screw tube into the pump inlet.
2. Adjust length of suction tube to desired level.
3. Screw pump into tank or barrel application until the spout faces the desired direction for dispensing.
4. Tighten the lock ring securely onto the tank or barrel
5. Attach air supply line to air inlet on pump.

WARNING

Do NOT exceed 100 PSI air pressure on air supply.

6. Pull up adjusting knob on top of the regulator.
7. Open air inlet valve to begin flow of fluid; discharge into a suitable container.
8. Adjust air pressure by rotating the knob on top of the regulator until a smooth flow is achieved.
9. Push regulator knob down to lock it into place.
10. Close air inlet valve to stop flow.
11. If applicable, attach dispensing hose to spout outlet; clamp securely in place.



NOTICE

TANK VENTING: In most cases it is desirable to vent the container being pumped from to prevent possible collapsing. The FR20V and FRHP32V hand pumps are self venting when screwed into a typical barrel. This is particularly important when working with Diesel Exhaust Fluid as exposure to air will crystallize the fluid instantly. It is critical to maintain the seal to a barrel or drum of Diesel Exhaust Fluid to maintain the integrity of the fluid.

About Diesel Exhaust Fluid (DEF)

The Fill-Rite DEF pump is designed to pump AUS32 (Aqueous Urea Solution 32.5%), better known as Diesel Exhaust Fluid, or “DEF”.

AUS32 is used by modern diesel engines which are equipped with an SCR (Selective Catalytic Reduction) system. DEF never comes into contact with the fuel; the common misconception is that it is an additive. DEF is carried on-board the vehicle in its own storage tank. It is injected into the exhaust gases as a post combustion process through an SCR where it breaks harmful NOx (Nitrous Oxide) emissions down into mostly Nitrogen and Oxygen.

Because the specific purity of the AUS32 solution is critical to the catalytic reaction, the Fill-Rite DEF pump is designed to maintain the integrity by using components made of materials that will not taint or alter the solutions chemical structure.

NOTICE

After initial assembly and installation, flush the entire dispensing system by pumping 1 - 2 gallons of DEF through it. This purges the system of air, and ensures any impurities that may have been in the system are washed out. Dispose of the Diesel Exhaust Fluid used to flush the system using approved Diesel Exhaust Fluid handling procedures; do not return the fluid to the drum or tote, or use it in a vehicle.

Troubleshooting: FR20V and FRHP32V Hand Pumps

Symptom	Cause	Cure
Pump will not prime	Suction line problem	Check for leaks or restrictions in suction line
	Jammed check valve	Inspect inlet and piston valves
	Fluid incompatibility	Consult fluid mfg. for compatibility with wetted materials
Low capacity	Excessive dirt in nozzle screen	Remove and clean screen
	Suction line problem	Check for leaks in suction line
Pump fluid leakage	Dirty seal	Clean O-ring and seat area
	Bad seal	Replace seal
	Gasket leakage	Tighten covers and joints
	Fluid incompatibility	Consult fluid manufacturer for compatibility with wetted materials

Troubleshooting: FRAP32V Air Operated Pump

Symptom	Cause	Cure
Pump air piston does not operate	Air pressure is too low; minimum recommended air pressure is 30 psi (2 bar)	Increase air supply pressure to between 30 psi and 100 psi (2 bar to 6 bar).
	Piston frozen in place (frost on air cylinder)*	Close air inlet valve and allow piston & cylinder to thaw (see * note below)
Low capacity	Low air pressure, or pressure has dropped below 30 psi (2 bar)	Close & re-open air inlet valve
	Piston frozen (see above)	If stalling occurs regularly, adjust the regulator to increase the air pressure

* After periods of extensive use, usually with a hose kit, the air piston on the FRAP32V air pump may freeze because of excess moisture in the air supply line. If this condition persists, install a filter, filter / lubricator, or a water separator to reduce moisture content in the air supply to the pump.

Accessories

The following accessories are available to help you tailor your pump to your specific needs

Part Number	Description	FR20V	FRHP32V	FRAP32V
KITHA32V	6' Hose and Ball Valve Kit	X	X	
KITHA32VMN	6' Hose and Manual Nozzle Kit			X
KITFR55DU	Drum / Barrel Tote Kit (wheeled platform for drum mobility)	X	X	X

Technical Information and Specifications

FR20V AND FRHP32V

Technical Data

- Output: 11 oz per stroke (33ml)

Fluid Compatibility (FR20V, FRHP32V & FRAP32V)

- Engine oils
- Diesel
- Antifreeze
- Paraffin
- Gear oils
- Hydraulic oils
- Mild acids*
- Degreasers

DEF Compatibility (FRHP32V & FRAP32V)

- AUS32 (Aqueous Urea Solution 32.5%) Diesel Exhaust Fluid

Wetted Materials (all pumps)

- Polypropylene (body and valves)
- Stainless Steel (inlet screen)
- Fluorocarbon (O-rings)

* Before using with acids or aggressive chemicals, check compatibility of wetted materials with the chemical manufacturer.

FRAP32V

Technical Data

- Ratio: 1:1
- Air Pressure Regulator: 100 PSI
- Air Inlet: 1/4" BSP
- Maximum Air Pressure: 100 PSI
- Minimum Air Pressure: 30 PSI
- Air Consumption: 30 gal/min
- Exhaust: Double Baffled
- Maximum Sound Level @ 1m (3'): 74 db

Output Data (approximately 8.5 oz/stroke when fully primed)

- Hydraulic Oils (ISO 32): 0 - 5 GPM
- Lubrication Oils (ISO 68): 0 - 4 GPM
- Gear Oils (ISO 220): 0 - 2.5 GPM
- Diesel Exhaust Fluid (AUS32): 0 - 6.5 GPM

Minimum Operating Temperature

It is recommended that the pump is not used below 36°F because ice formation may cause the regulator to malfunction.

Fill-Rite Limited Product Warranty Policy

Revision Date: August 1, 2014, Fill-Rite and Sotera Products

Fill-Rite Company ("Manufacturer") warrants each consumer buyer of its products ("Buyer") from date of sale that goods of its manufacture ("Goods") shall be free from defects of materials and workmanship. The duration of the warranty is as follows:

From Date of Sale	Not to Exceed the Following Period from Date of Manufacture	Product Series	
Five Years	60 Months	SP100 Series Pumps	400 Series Pumps
Two Years	27 Months	Heavy Duty Pumps and Meters, 820, 825, 850 Meters	Cabinet Pumps, Cabinet Meters, TN Meters, TM Meters, TS Meters
One Year	15 Months	Standard Duty Pumps, 1600 Pumps	Accessories, Parts

End users must contact the place where they purchased the product to process a warranty. "Place of purchase" is defined as any authorized Fill-Rite Distributor, including any and all retail stores, mail order houses, catalogue houses, on-line stores, commercial distributors.

Manufacturer's sole obligation under the foregoing warranties will be limited to either – at Manufacturer's option – replacing defective goods (subject to limitations hereinafter provided) or refunding the purchase price for such Goods theretofore paid by the buyer, and Buyers exclusive remedy for breach of any such warranties will be enforcement of such obligations of the Manufacturer. If the Manufacturer so requests the return of such Goods, the Goods will be redelivered to the manufacturer in accordance with Manufacturer's instructions FOB Factory.

The remedies contained herein shall constitute the sole recourse of the Buyer against the Manufacturer for breach of warranty. IN NO EVENT SHALL THE MANUFACTURER'S LIABILITY FOR ANY CLAIM FOR DAMAGES ARISING OUT OF THE MANUFACTURE, SALE, DELIVERY, OR USE OF THE GOODS EXCEED THE PURCHASE PRICE.

The foregoing warranties will not extend to goods subject to misuse, neglect, accident, improper installation or maintenance, or have been repaired by anyone other than the Manufacturer or its authorized representative.

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OF MERCHANTABILITY, FITNESS FOR PURPOSE OF ANY OTHER TYPE, WHETHER EXPRESSED OR IMPLIED. No person may vary the forgoing warranties or remedies, except in writing signed by a duly authorized officer of the Manufacturer. The Buyer's acceptance of delivery of the Goods constitutes acceptance of the foregoing warranties and remedies, and all conditions and limitations thereof.

Fill-Rite Company
8825 Aviation Drive
Fort Wayne, Indiana 46809 USA

T 1 (800) 720-5192
1 (260) 747-7524
F 1 (800) 866-4681

fillrite.com | sotera.com | gormanrupp.com